## **Technical data sheet**

#### **SPWT**

## **Stepped Party Wall Tie**



The SPWT has been specifically designed and engineered to connect separating walls of attached timber framed buildings. The SPWT is to be used for applications where the timber frame separating walls are stepped, typically in terraced or semi-detached housing, built on sloped elevations.

## **Features**

#### Material

#### Pre-galvanised Mild Steel - Z275

### **Features**

# The SPWT design ensures minimum material section for optimum sound performance.

- Meets the requirements of Part E of The Building Regulations (Resistance to the Passage of Sound)
- Compliant with Building Standards Scotland
  Section 5 (Noise)
- Compliant with E-WT-1 & E-WT-2 (Robust Details) for separating wall straps
- Suits timber frame separating wall with cavities from 50 to 75mm
- Supplied with SSH screw for fixing into the timber frames vertical stud



## Technical data sheet

## **SPWT**

## **Stepped Party Wall Tie**



## **Technical Data**

## Dimensions



References	Product Dimensions							
	Dimension [mm]				Holes			
	A	В	C	t	Flange A	Flange C		
					Ø4.1	Ø6.2		
SPWT	25	140	25	1.5	4	1		

## Performance Values



Complete Installation.

		Fas	teners		Performance Values		
References	ences Flange A		Flange C		Characteristic Load [kN]	Safe Working Loads [kN]	
	Qty	Туре	Qty	Type	$R_{5,k} = R_{6,k}$	$R_{5,SWL,LT} = R_{6,SWL,LT}$	
SPWT	4	N3.75x30	1	SSH6.0x60	2.6	1.8	

#### Notes:

- 1. R<sub>5</sub> and R<sub>6</sub> loads are tension and compression loads through the length of the tie
- 2. Performance values are based upon tests, with the SSH fixed through 9mm OSB into a 38mm wide face of the timber stud.

## **Technical data sheet**

#### **SPWT**

## **Stepped Party Wall Tie**



## Installation

#### Installation

- Fix the SPWT to the face of the vertical stud with 1 No SSH6.0x60 screw (supplied). Note, the SPWT can be screwed directly to the narrow face of the stud (minimum 38mm wide) or through the wall sheathing (minimum 9mm OSB) into the stud.
- The SPWT is then fixed to the top of the adjacent timber frame panels top rail with 4 No 3.75x30mm square twist nails (NOT supplied), ensuring a minimum 20mm nail edge distance.
- Ties are typically installed at 1200mm centres horizontaly, one row of ties per storey height.



SSH6.0x60 Installed into vertical stud of timber frame



3.75x30mm square twist nails installed into the top of the top rail of the timber frame wall



Complete Installation.



N3.75x30mm Sheradised Square Twist Nail

SSH Screw

2023-02-14

**SPWT** 









